

MARSHALLING SIGNALS

ASA REF: -	08/20	DATE OF ISSUE: -	06/08/2020	EFFECTIVE DATE: -	06/08/2020
------------	-------	------------------	------------	-------------------	------------

We have received increasing reports of incorrect signalling for ‘straight ahead’ when marshalling. For example:
 “straight ahead signal given with arms going from almost straight down to straight up (range of 160 deg. Movement instead of 90)”
 “straight ahead signal given with arm movement extending to 45 degrees below horizontal.”

Please ensure the correct signal is utilised, as detailed below:



(4)
 Bend extended arms at elbows and move wands up and down from chest height to head.

This is detailed in the Marshalling training course and in the CAP637 visual aid handbook. The link to this is provided below:

<http://publicapps.caa.co.uk/docs/33/CAP637%20Visual%20Aids%20Handbook.pdf>

If anyone would like to renew their Training, please contact training@eastmidlandsairport.com

END.

Originator: -	Compliance and Operations Analyst	Confirmed By: -	Head of Fire and Airfield Operations
---------------	-----------------------------------	-----------------	--------------------------------------